

User's Manual



Wall-Mounted, Modulating Gas, Condensing, Combination Boiler

Model FTCW 140,000 BTU/hr 199,000 BTU/hr

- Natural Gas (NG) Factory Configuration
- Propane Gas (LP) Field-Convertible

**FOR YOUR SAFETY:** This product must be installed and serviced by a professional service technician, qualified in hot water boiler and heater installation and maintenance. Improper installation and/or operation could create carbon monoxide gas in flue gases which could cause serious injury, property damage, or death. Improper installation and/or operation will void the warranty.

## 

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a nearby phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency, or gas supplier.

#### 

Assurez-vous de bien suivres les instructions données dans cette notice pour réduire au minimum le risque d'incendie ou d'explosion ou pour éviter tout dommage matériel, toute blessure ou la mort.

Ne pas entreposer ni utiliser d'essence ni d'autres vapeurs ou liquides inflammables dans le voisinage de cet appareil ou de tout autre appareil.

QUE FAIRE SI VOUS SENTEZ UNE ODEUR DE GAZ:

- Ne pas tenter d'allumer d'appareils.
- Ne touchez à aucun interrupteur. Ne pas vous servir des téléphones dansle bâtiment où vous êtes.
- Appelez immédiatement votre fournisseur de gaz depuis un voisin. Suivez les instructions du fournisseur.
- Si vous ne pouvez rejoindre le fournisseur de gaz, appelez le sservice des incendies.

L'installation et l'entretien doivent être assurés par un installateur ou un service d'entretien qualifié ou par le fournisseur de gaz.

#### CONTENTS

- 4. Control Setup and Operation......4-10
  - 1. Familiarizing yourself to



The combi FT is a wall mounted, condensing and fully modulating, residential boiler and water heater.

This Users Manual will guide you into the basics of operating your FT

Please reference the Installation and Operation Manual for complete details. Doc# 1318



Pas -

# 2. Caring For Your FT

Your FT will require very little maintenance. However, as with any fine appliance there are certain steps that should be taken to ensure continuing optimum performance.

#### 2.1 General Care

Keep the area around the FT clean and free from combustible materials, gasoline and other flammable liquids and vapors.

The FT must be completely isolated and protected from any source of corrosive chemical fumes such as trichlorethylene, perchlorethylene, chlorine, etc.

Keep bottom and top openings on the boiler free for proper ventilation of interior components.

Do not obstruct or block a free flow of air to the boiler to ensure proper ventilation.

If desired, clean the jacket surfaces with a damp cloth and mild detergent. Do not use flammable cleaning materials.

If sidewall vented, keep the vent terminal clear of obstructions — do not allow snow to cover the vent terminal. Clean the intake screen often, and then develop an appropriate maintenance schedule.

#### 2.2 Annual Inspection of Flue and Vents

Visually inspect the vent pipe once a year. Should any deterioration exist, have the affected parts replaced by a qualified service person.

## 2.3 In the Event of a Power Failure

The FT can not be operated during an electrical power outage. If there is an extended power outage with danger from freezing, then the FT (and all other water systems) should be drained completely. When draining the boiler, turn off main electrical disconnect switch. When placing back in service, refer to Section 3 of this Manual for instruction. All draining and filling must only be done by a qualified service person.

## 2.4 Full Service Every Year

In addition to the annual visual inspections, a qualified service agency should conduct a detailed inspection of all flue product carrying areas of the boiler and its venting system.



#	Name of Component
1	Air Vent (air eliminator)
2	Pressure Relief Valve
3	Air Intake Collar
4	Air Gas Mixing Pipe
5	Gas Valve
6	DHW Water Tank
7	Main PCB
8	Manual Power Switch (ON / OFF)
9	Recirculation Pump DHW / CH Primary Pump
10	'CH' Supply Connection
11	'CH' Return Connection
12	CH Pressure Gauge
13	DHW Outlet Connection
14	Gas Inlet Connection
15	DHW Inlet Connection (filter and flow restrictor)



Hydronic Supply	Hydro
-----------------	-------

#	Name of Component
16	Condensate Connection
17	Condensate Trap
18	Air Pressure Switch (condensate)
19	Mixing Valve
20	Terminal Block
21	Control Panel and Display
22	Heat Exchanger
23	Ignition Trans
24	Flame Detecting Sensor
25	Burner Case
26	BLDC Fan
27	Vent Pipe
28	Air Pressure Switch
29	Vent Pipe Collar
30	Sight Glass

# 3. Shut Down and Restart

### 3.1 To Start the FT

If drained, please refer to the Install and Operating Manual to ensure that the complete 'Setup' procedure has been followed before starting this boiler. A complete 'Setup' must be performed by a qualified service person.

## 3.2 Shutting Down the FT

- 1. Turn off the main electrical disconnect switch.
- 2. Close all manual gas valves.
- 3. If freezing is anticipated, drain FT and be sure to also protect building piping from freezing. All water must be removed from heat exchanger and condensate trap or else damage from freezing may occur. Please refer to the Install and Operating Manual.

This step to be performed by a qualified service person.



**The Control Display** has a Control Dial (E), 4 buttons (A, B, C, D), and a Liquid Crystal Display (with 72 back-lit segments). This section of this manual gives instruction on how to navigate into the many functions of the FT and to change temperature set points, set system variables and controller parameters.

	Dut	ttons		Functionality
	Duttons		PRESS (Tap)	PRESS and HOLD (5 seconds)
А	U	Display Power	Turns Control Display ON/OFF	
В		Modes	Tap to return to menu	(If Display Power was On ) <b>Status Display Mode</b> (If Display Power was Off ) <b>Installer Mode</b>
С	i	Hot Water	<b>DHW Set-Point LOW Range</b> 95 - 120°F (35 - 49°C)	DHW Set-Point HIGH Range 121 - 140°F (49.5 - 60°C)
D	<u>ئ</u> ال	Central Heat	CH set-point mode (boiler only)	Toggle (°C / °F)
Е	$\bigcirc$	Scroll / Select	Turn to scroll, tap to select (clockwise or counterclockwise)	

• Temperature Specifications Operating ambient Temperature Range : -10 to 60°C. Operating Relative Humidity up to: 90% at 40°C. Shipping & Storage Temperature Range of : -20 to 80°C.

# 4. The Control Display and Operation



#### 4. The Control Display and Operation (continued)

CH mode	Central Heat mode icon can be adjusted
Anti-freeze mode	Anti-freeze mode icon
Storage Heating mode	Stored Water Being Heated, can be adjusted
Lock mode	Buttons-locked mode icon
Communication	Communication icon
Summer mode	Only DHW Mode, can be adjusted (warm weather shutdown)
Status and Installer mode	The Status Mode or the Installer Mode is Active (all parameters)
Flame signal	Flame Signal icon
Pump icon	Water pump operation (CH or DHW) icon
Numeric Display	Number and character display, to display all parameters
DHW mode	Combination boiler Set Point, can be adjusted
Outside temp or 0-10 V mode	Operating by outside temperature or 0-10V

The LCD will illuminate when a user action is detected (a button is pressed) and will turn back off after 20 seconds.

\* NOTE: The display will not allow changes when the lock mode ((•)) is activated. To exit the Lock mode, press the 📲 button.

## 

Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control that may have been under water.

#### Operating Mode

After the Power is turned on, and/or the Control Display is turned on  $\bigcirc$ , the Control Display will go through a 'Start Up' checklist and briefly show a sequence of diagnostic codes before entering into the 'Operating Mode. It will then display the following information.



Indicate	Example
Current Operating Temperature	110°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
Display and Controller are communicating	llha
If flame detected	<u>aûa</u>
If pump is operating	
Outdoor sensor or 0-10V	11.18



Digital	Display	Status Display	Parameter	Description									
O:ot		Outdoor tempera	ature	Current Outdoor temperature									
A: Li or	A: GA	Flow unit		Current flow value(Li: L/m, GA: GPM)									
b: It		CH Return Wate	er Temperature	Current Return Wa	iter Sensor Tempera	ture							
C: Fr		Fan rpm		Current fan rpm va	lue								
d: Lc		Lock mode		Lock mode ON/OF	F								
E: oP		OP temperature		Current OP temper	rature								
F: dH H: Eh		DHW temperatu	re	Current DHW temp	perature								
		Exhaust temperation	ature	Current Exhaust te	mperature								
I:St		N/A		Not Used (Default	is 0)								
J: oH		Overheat tempe	rature	Current Overheat temperature									
	1: PH		Supply power time Supply power time x 100 hour										
	2: rh		Burner operation time	Burner operation time x 1 hour									
L: rt	3: rH	Burner Opera- tion Time	Burner operation time	Burner operation time x 1,000 hour									
	4: It	-	Ignition cycles	Ignition cycles x 10 times									
	5: IH		Ignition cycles	Ignition cycles x 1	0,000 times								
	•			1st Icon	2nd Icon	3rd Icon							
			condition for internal	Not Used	Internal CH Pump	3 Way Valve							
P: Ou			>- Off	$\Box \bigcirc$	$\Box \bigcirc$	$\bigcirc$							
		4	<u>-</u> V- On	$\bigcirc$	Ø	Q							

# To change any of the above listed Status Parameters,

Press and Hold Button B 💾 to get into the Status Display Mode.

Rotate Dial E until you find the Parameter that you wish to change. Tap Dial E to enter that Parameter.

Adjust to the setting that you require and then press (tap) Dial E to save and to Exit.

 DHW Set Point Change Modes
The display shows the following information when changing water heating temperature set points.

Changing between Celsius and Fahrenheit When the button D  $\bigcup_{F}^{E}$  is pressed (for more than 5 seconds), temperature unit will toggle between °C and °F.





Indicate	Example
Current DHW set-point temperature	120°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
If display is communicating with the main controller normally, the communication icon will be indicated.	لللته
When DHW set-point range is high : from 121°F (49.5°C) to 140°F (60.0°C)	H . 140°F
When changing DHW setpoint, the DHW icon will flash	HOH

\* Default DHW set-point is 120°F (49°C)

# • DHW 95-120°F (35 - 49°C) LOW range (Default)

**-To change LOW range,** press the C Button. The DHW icon and current DHW LOW will flash (a flashing value means it can be changed).

-Turn dial E clockwise to increase and counterclockwise to decrease until desired temperature is reached. -Press dial E to save setpoint changes.

# • DHW 121 - 140°F (49.5 - 60°C) HIGH range

**-To change HIGH range,** press and **HOLD** the C button for more than 5 seconds. The DHW icon and current DHW HIGH will flash (a flashing value means it can be changed).

-Turn dial E clockwise to increase and counterclockwise to decrease until desired temperature is reached. -Press dial E to save setpoint changes and to Exit.



Scalding may occur within 5 seconds at a setting of 140°F (60°C). Water temperatures over 125°F can cause severe burns, or death from scalding. Children, disabled, and elderly are at highest risk of being scalded. Read all instructions before setting temperature at appliance. Feel water before bathing or showering.



Changing between Celsius and Fahrenheit When the button D  $\iint_{\mathbb{F}}^{\mathbb{F}}$  is pressed (for more than 5 seconds), temperature unit will toggle between °C and °F.



Indicate	Example
Current Operating Temperature	110°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
Display and Controller are communicating	للله
If flame detected	<u>aûa</u>
If pump is operating	$\bigcirc$
When changing CH Setpoint, the CH Icon will flash	

Default CH set-point is 120°F (49°C) CH set-point range is 86 - 180°F (30.0 ~ 82.0°C)

# **To change CH Setpoint,** press the D **b** button. The CH Icon and current CH Setpoint will flash.

Turn the E dial clockwise to increase, and counterclockwise to decrease CH setpoint, until desired temperature is reached.

Press E dial to save changes and to Exit.

## 5.7 Storage Mode



Indicate	Example
Current Operating Temperature	110°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
Display and Controller are communicating	llha
If flame detected	බො
Storage mode indication	
If Pump is operating	$\bigcirc$

# To change Storage Mode Temp, First turn OFF the power to the Control Display.

Then Press and Hold Button B 🔡 to get into the Installer Mode.

Rotate Dial E until you find **5:St** Tap Dial E to enter Storage Mode. Storage Mode indicates that the boiler is heating the water held in the internal storage tank. When Storage Mode is active, the display will appear as shown.

Turn the E dial clockwise to increase, and counterclockwise to decrease setting. Press E dial to save changes and to Exit.

NI	otes														
		5.													

Notes:										

	Dim	anai	000.0	nd c	nocif	icatio		ubioo	t to a	hand		thout	notic	no in	2000	rdan	00.14	ith ar	ur nol	icy of	Foor	tinuc		odu	nt im-	mor
2900D	וווש	511310	<i>J</i> 13 d	inu Sj	Jecill	Janc	113 31	JUJEC	0 0	anan g					F			06	,, pol	icy UI	COIL		us pi	Juu	л IIIIр	 en
H2372900D											ENER	GV STA	К В	с	LIST	ED	US									



Customer Service and Product Support: 800.900.9276 • Fax 800.559.1583 20 Industrial Way, Rochester, NH, USA 03867