



User's Manual

THE FT SERIES

Floor-Standing, Modulating
Gas, Condensing, Combination Boiler

Model FTCTF

140,000 BTU/hr

199,000 BTU/hr

- Natural Gas (NG) - Factory Configuration
- Propane Gas (LP) - Field-Convertible



FOR YOUR SAFETY: This product must be installed and serviced by a professional service technician, qualified in hot water boiler and heater installation and maintenance. Improper installation and/or operation could create carbon monoxide gas in flue gases which could cause serious injury, property damage, or death. Improper installation and/or operation will void the warranty.

⚠ WARNING

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a nearby phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency, or gas supplier.

⚠ AVERTISSEMENT

Assurez-vous de bien suivre les instructions données dans cette notice pour réduire au minimum le risque d'incendie ou d'explosion ou pour éviter tout dommage matériel, toute blessure ou la mort.

Ne pas entreposer ni utiliser d'essence ni d'autres vapeurs ou liquides inflammables dans le voisinage de cet appareil ou de tout autre appareil.

QUE FAIRE SI VOUS SENTEZ UNE ODEUR DE GAZ:

- Ne pas tenter d'allumer d'appareils.
- Ne touchez à aucun interrupteur. Ne pas vous servir des téléphones dans le bâtiment où vous êtes.
- Appelez immédiatement votre fournisseur de gaz depuis un voisin. Suivez les instructions du fournisseur.
- Si vous ne pouvez rejoindre le fournisseur de gaz, appelez le service des incendies.

L'installation et l'entretien doivent être assurés par un installateur ou un service d'entretien qualifié ou par le fournisseur de gaz.

CONTENTS	Pgs -
1. Familiarizing yourself to the FT	2
2. Caring For Your FT	2
3. Start Up and Shut Down.	4
4. Control Display and Operation	4-10


1. Familiarizing yourself to

THE FT

The FT is a floor standing, condensing and fully modulating, residential boiler and water heater.

This Users Manual will guide you into the basics of operating your FT

Please reference the Installation and Operation Manual for complete details.
Document # 1320



2. Caring For Your FT

Your FT will require very little maintenance. However, as with any fine appliance, there are certain steps that should be taken to ensure continuing optimum performance.

2.1 General Care

Keep the area around the FT clean and free from combustible materials, gasoline and other flammable liquids and vapors.

The FT must be completely isolated and protected from any source of corrosive chemical fumes such as trichlorethylene, perchlorethylene, chlorine, etc.

Keep bottom and top openings on the boiler free for proper ventilation of interior components.

Do not obstruct or block a free flow of air to the boiler to ensure proper ventilation.

If desired, clean the jacket surfaces with a damp cloth and mild detergent. Do not use flammable cleaning materials.

If sidewall vented, keep the vent terminal clear of obstructions — do not allow snow to cover the vent terminal. Clean the intake screen often, and then develop an appropriate maintenance schedule.

2.2 Annual Inspection of Flue and Vents

Visually inspect the vent pipe once a year. Should any deterioration exist, have the affected parts replaced by a qualified service person.



2.3 In the Event of a Power Failure

The FT can not be operated during an electrical power outage. If there is an extended power outage with danger from freezing, then the FT (and all other water systems) should be drained completely. When draining this combi boiler, turn off main electrical disconnect switch. When placing back in service, refer to Section 3 of this Manual for instruction. All draining and filling must only be done by a qualified service person.

2.4 Full Service Every Year

In addition to the annual visual inspections, a qualified service agency should conduct a detailed inspection of all flue product carrying areas of the boiler and its venting system.

Shown is the FTCF140. The FTCF199 is very similar.



Note: The greatest installation difference between the FTCF140 and FTCF199, other than general output capability (BTU's), is that the air inlet and exhaust vent are opposite.

NO	Name of Component
2	Air Pressure Sensor
3	BLDC FAN
4	PCB Bracket
5	Flame Detection Sensor
6	Flame Detection Window
7	Manual Switch
8	Display Control
9	Exhaust Pipe
10	Recirculation Pump(CH)
11	Mixing Valve
12	Recirculation Pump(DHW)
13	Hot Water Ass'y
14	Water Discharge Valve
15	Water Discharge Adapter
16	Condensate Trap Adapter

NO	Name of Component
17	Condensate Hose 1
18	DHW Inlet Adapter
19	Condensate Trap
20	DHW Outlet Adapter
21	Condensate Hose 2
22	CH Return Adapter
23	Air Pressure Switch
24	CH Supply Adapter
25	Heat Exchanger
26	Gas Inlet Adapter
27	Gas Valve
28	Air Vent
29	Ignition Transformer
30	Igniter
31	Air Intake Pipe

3. Shut Down and Restart


3.1 To Start the FT

If drained, please refer to the Install and Operating Manual to ensure that the complete ‘Setup’ procedure has been followed before starting this boiler. A complete ‘Setup’ must be performed by a qualified service person.

3.2 Shutting Down the FT

- 1. Turn off the main electrical disconnect switch.
- 2. Close all manual gas valves.
- 3. If freezing is anticipated, drain the FT and be sure to also protect the building piping from freezing. All water must be removed from heat exchanger and condensate trap or else damage from freezing may occur. Please refer to the Install and Operating Manual. This step to be performed by a qualified service person.

4. The Control Display and Operation




The **Control Display** has a Control Dial (E), 4 buttons (A, B, C, D), and a Liquid Crystal Display (with 72 back-lit segments). This section of this manual gives instruction on how to navigate into the many functions of the FT and to change temperature set points, set system variables and controller parameters.

Buttons			Functionality	
			PRESS (Tap)	PRESS and HOLD (5 seconds)
A		Display Power	Turns Control Display ON/OFF	
B		Modes	Tap to return to menu	(If Display Power was On) Status Display Mode (If Display Power was Off) Installer Mode
C		Hot Water	DHW Set-Point LOW Range 95 - 120°F (35 - 49°C)	DHW Set-Point HIGH Range 121 - 140°F (49.5 - 60°C)
D		Central Heat	CH set-point mode (boiler only)	Toggle (°C / °F)
E		Scroll / Select	Turn to scroll, tap to select (clockwise or counterclockwise)	

- Temperature Specifications
Operating ambient Temperature Range : -10 to 60°C.
Operating Relative Humidity up to: 90% at 40°C.
Shipping & Storage Temperature Range of : -20 to 80°C.

4. The Control Display and Operation (continued)



CH mode	Central Heat mode icon can be adjusted
Anti-freeze mode	Anti-freeze mode icon
Storage Heating mode	Stored Water Being Heated, can be adjusted
Lock mode	Buttons-locked mode icon
Communication	Communication icon
Summer mode	Only DHW Mode, can be adjusted (warm weather shutdown)
Status and Installer mode	The Status Mode or the Installer Mode is Active (all parameters)
Flame signal	Flame Signal icon
Pump icon	Water pump operation (CH or DHW) icon
Numeric Display	Number and character display, to display all parameters
DHW mode	Combination boiler Set Point, can be adjusted
Outside temp or 0-10 V mode	Operating by outside temperature or 0-10V

The LCD will illuminate when a user action is detected (a button is pressed) and will turn back off after 20 seconds.

* NOTE: The display will not allow changes when the lock mode (Ⓛ) is activated.

To exit the Lock mode, press the  button.


WARNING

Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control that may have been under water.

Operating Mode


■ Operating Mode

After the Power is turned on, and/or the Control Display is turned on , the Control Display will go through a 'Start Up' checklist and briefly show a sequence of diagnostic codes before entering into the 'Operating Mode'. It will then display the following information.



Indicate	Example
Current Operating Temperature	110°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
Display and Controller are communicating	
If flame detected	
If pump is operating	
Outdoor sensor or 0-10V	

Status Display Mode



Digital Display		Status Display Parameter		Description		
O:ot		Outdoor temperature		Current Outdoor temperature		
A: Li or A: GA		Flow unit		Current flow value(Li: L/m, GA: GPM)		
b: lt		CH Return Water Temperature		Current Return Water Sensor Temperature		
C: Fr		Fan rpm		Current fan rpm value		
d: Lc		Lock mode		Lock mode ON/OFF		
E: oP		OP temperature		Current OP temperature		
F: dH		DHW temperature		Current DHW temperature		
H: Eh		Exhaust temperature		Current Exhaust temperature		
I : St		Storage Temperature		Current Storage Temperature		
J: oH		Overheat temperature		Current Overheat temperature		
L: rt	1: PH	Burner Operation Time	Supply power time	Supply power time x 100 hour		
	2: rh		Burner operation time	Burner operation time x 1 hour		
	3: rH		Burner operation time	Burner operation time x 1,000 hour		
	4: lt		Ignition cycles	Ignition cycles x 10 times		
	5: IH		Ignition cycles	Ignition cycles x 10,000 times		
P: Ou		Displays output condition for internal primary pump and three way valve.  Off  On		1st Icon	2nd Icon	3rd Icon
				Internal Pump	CH Pump	Not Used
						
						

To change any of the above listed Status Parameters,

Press and Hold Button B  to get into the Status Display Mode.

Rotate Dial E until you find the Parameter that you wish to change. Tap Dial E to enter that Parameter.

All other modes except d:Lc (Lock mode) are to display current status, therefore you need to check the current setting and press button to exit.


DHW Set Point Change Mode

■ DHW Set Point Change Modes

The display shows the following information when changing water heating temperature set points.

Changing between Celsius and Fahrenheit

When the button D  is pressed (for more than 5 seconds), temperature unit will toggle between °C and °F.



Indicate	Example
Current DHW set-point temperature	125°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
If display is communicating with the main controller normally, the communication icon will be indicated.	
When DHW set-point range is high : from 121°F (49.5°C) to 140°F (60.0°C)	H . 140°F
When changing DHW setpoint, the DHW icon will flash	

* Default DHW set-point is 125°F (51°C)

• DHW 95-120°F (35 - 49°C) LOW range (Default)

- To change LOW range, press the C Button. The DHW icon and current DHW LOW will flash (a flashing value means it can be changed).
- Turn dial E clockwise to increase and counterclockwise to decrease until desired temperature is reached.
- Press dial E to save setpoint changes.

• DHW 121 - 140°F (49.5 - 60°C) HIGH range

- To change HIGH range, press and HOLD the C button for more than 5 seconds. The DHW icon and current DHW HIGH will flash (a flashing value means it can be changed).
- Turn dial E clockwise to increase and counterclockwise to decrease until desired temperature is reached.
- Press dial E to save setpoint changes and to Exit.


 DANGER

Scalding may occur within 5 seconds at a setting of 140°F (60°C). Water temperatures over 125°F can cause severe burns, or death from scalding. Children, disabled, and elderly are at highest risk of being scalded. Read all instructions before setting temperature at appliance. Feel water before bathing or showering.



CH Set Point Change Mode

Changing between Celsius and Fahrenheit
When the button D  is pressed (for more than 5 seconds), temperature unit will toggle between °C and °F.



Indicate	Example
Current Operating Temperature	110°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
Display and Controller are communicating	
If flame detected	
If pump is operating	
When changing CH Setpoint, the CH Icon will flash	


Default CH set-point is 120°F (49°C)
CH set-point range is 86 - 180°F (30.0 ~ 82.0°C)

To change CH Setpoint, press the button D  button. The CH Icon and current CH Setpoint will flash.

Turn the E dial clockwise to increase, and counterclockwise to decrease CH setpoint, until desired temperature is reached.

Press E dial to save changes and to Exit.

Storage Mode



Indicate	Example
Current Operating Temperature	110°F
Temperature sign Celsius or Fahrenheit letter	°C or °F
Display and Controller are communicating	
If flame detected	
Storage mode indication	
If Pump is operating	

To change Storage Mode Temp, First turn OFF the power to the Control Display.


Then Press and Hold Button B  to get into the Installer Mode.

Rotate Dial E until you find **24:SF** Tap Dial E to enter Storage Mode. Storage Mode indicates that the boiler is heating the water held in the internal storage tank. When Storage Mode is active, the display will appear as shown.

Turn the E dial clockwise to increase, and counterclockwise to decrease setting.

Press E dial to save changes and to Exit.

Notes:



Dimensions and specifications subject to change without notice in accordance with our policy of continuous product improvement.

H2373100B

