



REPLACEMENT PARTS LIST

Horizontal & Vertical Wall Hung Models




BW50H/V
BW80H/V
BW100H/V
BW120H/V
BW150H/V




Effective: September, 2024
ECO 8819

**NOTE: BOTH MODEL AND
SERIAL NUMBERS ARE
REQUIRED FOR ORDERING
REPLACEMENTS PARTS.**

Dimensions and specifications subject to
change without notice.



HORIZONTAL INSTALLATION



VERTICAL INSTALLATION

	Part Description	Model BW50 (H/V)	Model BW80 (H/V)	Model BW100 (H/V)	Model BW120 (H/V)	Model BW150 (H/V)
6	Anode	487176	487177	487179	487179	102594
1	Heating Element [#]	544038				
2	Gasket	580477				
3	Lens	594840				
7	Pilot Indicator	765230				
8	Outlet Tube	540652				
9	Protective Cap	564521				
11	Temperature Control Knob	564403				
12	Thermometer	564363				
13	Flange	580450				
19	Gasket for Vertical Anode	482950				
20	Spacer Bushing	580449				
23	Thermostat w/ Safety Cut Out	548480 (for H-version) / 409511 (for V-version)				
34	Inlet	536348				
36	Pressure & Check Safety Valve	580442				
99	Foot Guards	760509				
147	T & P Valve	566158*				
	* Does not come with general models or -GCC models					
	* Comes standard with -KSA models					
	[#] 2kW / 230V nominal heating element					



Technical Support 1-800-334-3393
Email techsupport@bradfordwhite.com
Warranty 1-800-531-2111
Email warranty@bradfordwhite.com
Service Parts 1-800-538-2020
Email parts@bradfordwhite.com

International

General Contact international@bradfordwhite.com