




TANKLESS WATER HEATER REPLACEMENT PARTS LIST

Infiniti® GS Series Models

Models Covered:
RTGS150N1
RTGS150X1




Effective: July, 2026
ECO 9013

**NOTE: BOTH MODEL AND SERIAL
NUMBERS ARE REQUIRED FOR
ORDERING REPLACEMENT PARTS**


Dimensions and specifications
subject to change without notice.




As required by the state of California Proposition 65.




Item Description	Model RTGS150(N,X)1
1 Exhaust Vent Kit With Items 10, 48, 49, 67	415-57113-00
2 Intake Inlet Duct Kit With Items 11, 48, 50	415-57116-00
3 Circuit Board	415-57123-00
4 Terminal Block	415-57122-00
5 Control Display Standard	415-57150-00
6 Main Power Switch	415-57121-00
7 Ignition Transformer Assembly	415-57174-00
8 Heat Exchanger Kit	415-57156-00
9 Exhaust Vent Cap Kit With Item 49	415-57114-00
10 Air Intake Filter Assembly	415-57117-00
47 Exhaust And Intake Gasket	265-57115-00
48 O-Ring (.28") (P7)	265-57139-00
49 Air Intake Filter Gasket	265-57118-00
66 O-Ring (2.4") (P62)	265-57141-00
67 O-Ring Kit	415-57153-00







Item Description	Model RTGS150(N,X)1
8 Heat Exchanger Kit	415-57156-00
11 Blower Kit With Items 13, 52	415-57162-00
12 Silencer Body Assembly	415-57163-00
13 Conversion Kit (Lp To Ng)	415-57167-00
Conversion Kit (Ng To Lp)	415-57168-00
14 Damper Gasket Assembly	415-57161-00
15 Burner Head Kit With Gaskets	415-57160-00
16 Exhaust Pipe Sub Kit With Item 18	415-57165-00
17 Exhaust Temperature Sensor	415-57166-00
18 Flame Detector Sensor	415-57173-00
19 Flame Detector Sensor Bracketry	415-57157-00
20 Ignition Rod With Gasket	415-57158-00
50 Nozzle Gasket	265-57169-00
51 O-Ring (P62) Blower Fan	265-57177-00
52 Exhaust Gasket	265-57164-00
53 Ignition Rod Gasket	265-57159-00





Item Description	Model
	RTGS150(N,X)1
21 Water Leak Detector	415-57125-00
22 Overheat Switch 15C (With Bracket)	415-57178-00
23 Power Cord	415-57179-00
54 Wire Through Way Gasket	265-57124-00



Item Description	Model RTGS150(N,X)1
24 Hot Water Outlet Block Kit With Items 37, 57	415-57142-00
25 Hot Water Outlet Pipe Kit With Items 38, 57	415-57144-00
26 Mixing T Block With Gaskets	415-57203-00
27 Mixing Valve With Gaskets	415-57146-00
28 Hot Water Outlet Pipe 2	415-57200-00
29 Domestic Hot Water Supply Pipe Kit With Item 39	415-57133-00
30 Mixing Pipe With Gaskets	415-57195-00
31 Cold Water T Block With Gaskets	415-57199-00
32 Flow Control Valve	415-57132-00
33 Cold Water Inlet Block Kit With Items 40, 41, 56	415-57129-00
34 Hx Inlet Pipe (Standard) With Items 36, 57, 65	415-57202-00
35 Ceramic Heater Harness	415-57181-00
55 Block Gasket (.63") (P16)	265-57137-00
56 Block Gasket (.71") (P18)	265-57151-00
57 Block Gasket (.6") (P15)	265-57152-00
61 Hex Clip	265-57155-00
62 Star Clip (Large)	265-57154-00
63 Star Clip (Small)	265-57138-00
64 Ceramic Heater Bracket	265-57182-00



Item Description	Model RTGS150(N,X)1
24 Hot Water Outlet Block Kit With Items 37, 57	415-57142-00
25 Hot Water Outlet Pipe Kit With Items 38, 57	415-57144-00
29 Domestic Hot Water Supply Pipe Kit With Item 39	415-57133-00
33 Cold Water Inlet Block Kit With Items 40, 41, 56	415-57129-00
36 Hot Water Temperature Sensor	415-57143-00
37 Overheat Switch (95C)	415-57145-00
38 Domestic Hot Water Temperature Sensor	415-57134-00
39 Cold Water Temperature Sensor	415-57131-00
40 Recirculation Return Filter	415-57130-00
55 Block Gasket (.63") (P16)	265-57137-00
56 Block Gasket (.71") (P18)	265-57151-00



Item Description	Model RTGS150(N,X)1
41 Gas Valve Outlet Pipe	415-57194-00
42 Gas Valve Assembly	415-57171-00
43 Gas Inlet Nipple	415-57126-00
44 Condensate Hose	415-57128-00
45 Air Pressure Sensor Assembly	415-57119-00
46 Siphon Assembly	415-57127-00
58 15A Gasket (Green)	265-57170-00
59 Epdm O-Ring (P22)	265-57176-00
60 P4 Customer Gasket	265-57172-00
65 Two Around Clip	265-57175-00



United States

Sales	1-800-523-2931
Technical Support	1-800-334-3393
Email	<i>techsupport@bradfordwhite.com</i>
Warranty	1-800-531-2111
Email	<i>warranty@bradfordwhite.com</i>
Service Parts	1-800-532-4020
Email	<i>parts@bradfordwhite.com</i>

Canada

Sales	1-866-690-0961 1-905-203-0600
Fax	905-636-0666
Technical Support	1-800-334-3393
Email	<i>techsupport@bradfordwhite.com</i>
Warranty	1-800-531-2111
Email	<i>warranty@bradfordwhite.com</i>
Service Parts and Orders	<i>ca.orders@bradfordwhite.com</i>

For U.S. and Canada field service, contact your professional installer or local Bradford White sales representative.

International

General Contact	<i>international@bradfordwhite.com</i>
------------------------	---